

Automatic Floss Bagger

Part No. 51009
Revised June 1996

Instruction Manual Model #3044



 **GOLD MEDAL®**
FUNFOOD EQUIPMENT & SUPPLIES

Cincinnati, OH 45214-2089 USA

SAFETY PRECAUTIONS

	 DANGER Machine must be properly grounded to prevent electrical shock to personnel. Do NOT immerse the equipment in water. Always unplug the equipment before cleaning or servicing.
	 WARNING ALWAYS wear safety glasses when servicing this equipment.
	 WARNING Any alterations to this equipment will void the warranty and may cause a dangerous situation. NEVER make alterations to the equipment. Make sure all machine switches are in the off position before plugging the equipment into the receptacle.
	 CAUTION Do NOT allow direct contact with this equipment and the general public when used in food service locations. Only personnel that are trained and familiar with the equipment should operate the equipment. Carefully read all installation instructions before operation.
	 CAUTION This machine is NOT to be operated by minors. Minors are classified as anyone under the age of 18.

NOTE

The information, specifications and illustrations contained in this manual represent the latest data available at time of publication. Right is reserved to make changes as required at the discretion of Gold Medal Products Company without notice.

OPERATING INSTRUCTIONS


The Automatic Floss Bagger is the "third hand" needed for bagging cotton candy. The Bagger has mounts for the bracket attached to the bag packs. Place the bracket on these mounts and slide the bracket to secure. Secure the Bagger to a smooth surface with the suction-cup feet and plug the machine in. The Automatic Floss Bagger is now ready to help boost your cotton candy sales. Just turn on the switch and the blower will open the front bag. Follow the procedures on the following pages to put the cotton candy in the bag.

BAGGING COTTON CANDY

Hold bag open with one hand while grasping cotton candy cone with the other hand. Rotate the serving down into the bag. Twist the bag top after cone and floss are inside. Tie and display.

FOR MAXIMUM SALES

Change colors every 10-25 cones. Keep your display full at all times. Always use Gold Medal Flossugar.



CAUTION

Keep hands
away from
spinning
head!


MAKING FLOSS

Pick a cone; if it sticks in the stack of cones, twist it off the stack.


Hold an inch or two of the pointed end of the cone between two fingers and a thumb. With a light flicking action, roll cone in the web of floss building up in the pan. Lift the cone up with the ring of floss attached and rotate the cone to wrap the floss. **DO NOT** roll floss while the cone is inside the pan. This will pack the floss too tightly.

If the floss sticks to the cone, pass the cone near the spinner head to pick up a "starter" of melted sugar. Lift the cone out of the pan and wrap the floss with a figure eight movement of the hand. This leaves giant pockets and makes the final product appear larger.


Make sure room humidity is not too high, or product will be too firm.

1

Grip cone as shown.

2





Break into web of floss
with the cone.

3

Wind the sugar onto
the cone

4

Lift web of floss from the
pan and roll onto the cone.

5**6****7****8**

MAINTENANCE INSTRUCTIONS

	⚠ CAUTION
	THE FOLLOWING SECTIONS OF THIS MANUAL ARE INTENDED ONLY FOR QUALIFIED SERVICE PERSONNEL WHO ARE FAMILIAR WITH ELECTRICAL EQUIPMENT. THESE ARE NOT INTENDED FOR THE OPERATOR.

	⚠ WARNING
	Adequate eye protection must be used when servicing this equipment to prevent the possibility of injury.

	⚠ DANGER
	Do NOT immerse the equipment in water. Unplug your machine before servicing.

ORDERING SPARE PARTS


1. Identify the desired part by checking it against the photos, illustrations, and/or the parts list.
2. When ordering, please include part number, part name, and quantity desired.
3. Please include your model name and machine serial number (located on the machine nameplate) with your order.
4. Address all parts orders to:

Parts Department
Gold Medal Products Co.
2001 Dalton Avenue
Cincinnati, Ohio 45214

or, place orders at:

(513) 381-1313
Fax: (513) 381-1570
E-mail: goldme19@eos.net

FLOSS BAGGER ASSEMBLY



AUTOMATIC FLOSS BAGGER PARTS

Item No.	Part No.	Description
1	51001	Flossbagger Cabinet Weldment
2	47010	Label, Safe Operating Instructions
3	74119	Label, Warning Disconnect Power
4	42159	Label, Floss Advertisement
5	76097	Warning, Unplug to Clean
6	51002	Front Panel Weldment
7	51005	Blower Motor, 120V, 60Hz
8	51003	Bag Holder
9	74141	Screw, #8-32 x $\frac{3}{8}$ " Rd. Hd. Ph.
10	44017	Rubber Suction Feet
11	44016	Lead-In Cord
12	47201	Switch, Motor and Light
13	82220	Strain Relief, #SR-6W-1
14	74149	Hex Nut, #8-32
15	46647	Screw, #10-24 x $\frac{3}{8}$ " Pn. Hd. Sl.
16	76022	Screw, #10-24 x 1" Ph. Pan Hd.
17	49130	Nut, Flex Lock #10-24 Thd.
18	76077	Hex Nut, #10-24

PARTS NOT SHOWN

3044	Floss Bagger
49133	Dead End Splice
51008	Making & Bagging Cotton Candy
51009	Manual Floss Bagger
51011	Carton Floss Bagger

ACCESSORIES

3065	Quick Bags 12" x 18" Red Clown Design, Header Pack, 1,000 per Pack
3064	Plain Quik-Pak Bags (same as above but plain)
3063	Super Jumbo Floss Bags, 11" x 26", Header Pack, 500 per Case
3061	Regular Floss Bags, 8" x 14" x 18" Bulk Pack, 1,000 per Case
3045	Wall Mount Bracket for regular bags
3210	Counter Model Floss Tree
3211	Floor Model Floss Tree
3066	Kwik-Lok Bag Closures, per 1,000

WARRANTY

WE WARRANT to the original purchaser the Gold Medal equipment sold by us to be free from defects in material or workmanship under normal use and service. Our obligation under this warranty shall be limited to the repair or replacement of any defective part for a period of six (6) months from the date of sale to the Original Purchaser with regard to labor and two (2) years with regard to parts and does not cover damage to the equipment caused by accident, alteration, improper use, voltage, abuse, or failure to follow instructions.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON OUR PART, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. We neither assume, nor authorize any other person to assume for us, any other obligation or liability in connection with the sale of said GOLD MEDAL equipment or any part thereof.

The term "Original Purchaser" as used in this warranty shall be deemed to mean that person, firm, association, or corporation who was billed by the GOLD MEDAL PRODUCTS COMPANY, or their authorized distributor for the equipment.

THIS WARRANTY HAS NO EFFECT AND IS VOID UNLESS THE ORIGINAL PURCHASER FIRST CALLS GOLD MEDAL PRODUCTS COMPANY AT 1-800-428-2676 TO DISCUSS WITH OUR SERVICE REPRESENTATIVE THE EQUIPMENT PROBLEM, AND, IF NECESSARY, FOR INSTRUCTIONS CONCERNING THE REPAIR OR REPLACEMENT OF PARTS.

NOTE: This equipment is manufactured and sold for commercial use only.



**GOLD MEDAL PRODUCTS COMPANY
2001 DALTON AVENUE
CINCINNATI, OHIO 45214-2089 USA**