


DUCK POND

Instruction Manual

Model #7759



FUNFOOD EQUIPMENT & SUPPLIES

Cincinnati, OH 45241-4807 USA

SAFETY PRECAUTIONS

	 DANGER
	Pump must be properly grounded to prevent electrical shock. Connect pump to a receptacle with a GFCI (Ground Fault Circuit Interrupter). Always unplug the pump before servicing

	 WARNING
	Drowning Hazard, always supervise children. Do NOT allow children to operate.

	 WARNING
	To avoid injury, do not sit or climb on games. Do NOT use this game as a table.

	 WARNING
	Do NOT drop the pump. If the pump has been dropped or damaged, do NOT use.

	 CAUTION
	This machine is NOT to be operated by minors. Minors are classified as anyone under the age of 18.

NOTE

The information, specifications and illustrations contained in this manual represent the latest data available at time of publication. Right is reserved to make changes as required at the discretion of Gold Medal Products Company without notice.


INSTALLATION INSTRUCTIONS

CHECKING SHIPMENT


The DUCK POND is shipped in a corrugated carton. Unpack all cartons and check thoroughly for any damage, which may have occurred during transit. Damage claims should be filed immediately with the transportation company.

ASSEMBLY


Step 1. Assemble legs to the pond base by inserting the tapered ends of the leg into the tapered holes on the underside of the pond base.



Step 2. Assemble the pump components as shown.



Step 3. Place the pump in the duck pond with the output nozzle pointing to the closest end. Place the cover plate over the side with the pump and secure pump chord to cover plate. The cover should be placed with the hole furthest away from the pump.



OPERATING INSTRUCTIONS

1. Fill trough with enough water to float the ducks.
2. Using the marker provided, place marks on bottom side of ducks to indicate winners.
3. Place ducks in the water.
4. Plug the pump chord into the GFCI (Ground Fault Circuit Interrupter) receptacle provided.
5. Players reach through the hole in the cover to select a duck.

ELECTRICAL REQUIREMENTS

The voltage for the duck pond pump is 120VAC. The pump must be plugged into the GFCI (Ground Fault Circuit Interrupter) receptacle provided.

	⚠ DANGER Pump must be properly grounded to prevent electrical shock. Connect pump to a receptacle with a GFCI (Ground Fault Circuit Interrupter). Always unplug the pump before servicing
--	---

CARE AND CLEANING

At the end of the day, unplug the pump from the power source and remove the ducks from the pond. Attach the long piece of tubing provided to the output nozzle of the pump. Place the other end of the tubing in a bucket. Use the pump to drain the duck pond into the bucket. Empty all water from the duck pond. Once all of the water has been drained from the duck pond, use a clean cloth to wipe dry.

ORDERING SPARE PARTS

1. Identify the worn or broken part by checking it with the illustrations and parts list.
2. When ordering parts, include part number, part name, and quantity required.
3. Include you model name and machine serial number (found on nameplate) with your order.
4. Address orders to:

Parts Department
Gold Medal Products Co.
10700 Medallion Drive
Cincinnati, Ohio 45241-4807

or, place orders at:

(800) 543-0862
(513) 769-7676
Fax: (513) 769-8500
E-mail: info@gmpopcorn.com
www.gmpopcorn.com

PARTS LIST

<u>DESCRIPTION</u>	<u>PART NO.</u>	<u>QTY.</u>
DUCK POND	52121	1
LEG	52111	2
PUMP	52120	1
DUCK POND COVER	52119	1
DUCKS	52134	12
PUMP FITTING	52139	1
TUBING	52155	.188 FT
TUBING	52156	2 FT
EDGE TRIM	39114	1.568 FT
CORD CLIP	75269	2
PAINT MARKER	52144	1
GFCI (GROUND FAULT PLUG)	52143	1

SPECIFICATIONS

Duck Pond with Legs attached:

Height: 24-3/4 inches
Length: 60 inches
Depth: 26 inches

WARRANTY

WE WARRANT to the original purchaser the Gold Medal equipment sold by us to be free from defects in material or workmanship under normal use and service. Our obligation under this warranty shall be limited to the repair or replacement of any defective part for a period of six (6) months from the date of sale to the Original Purchaser with regard to labor and one (1) year with regard to parts and does not cover damage to the equipment caused by accident, alteration, improper use, voltage, abuse, or failure to follow instructions.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON OUR PART, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. We neither assume, nor authorize any other person to assume for us, any other obligation or liability in connection with the sale of said GOLD MEDAL equipment or any part thereof.

The term "Original Purchaser" as used in this warranty shall be deemed to mean that person, firm, association, or corporation who was billed by the GOLD MEDAL PRODUCTS COMPANY, or their authorized distributor for the equipment.

THIS WARRANTY HAS NO EFFECT AND IS VOID UNLESS THE ORIGINAL PURCHASER FIRST CALLS GOLD MEDAL PRODUCTS COMPANY AT 1-800-543-0862 TO DISCUSS WITH OUR SERVICE REPRESENTATIVE THE EQUIPMENT PROBLEM, AND, IF NECESSARY, FOR INSTRUCTIONS CONCERNING THE REPAIR OR REPLACEMENT OF PARTS.

NOTE: This equipment is manufactured and sold for commercial use only.



GOLD MEDAL PRODUCTS COMPANY
10700 Medallion Drive
Cincinnati, Ohio 45241-4807 USA